

## Battery Model (Cordless)

This is a Cordless Model which runs with AA batteries.

### How to Use:

- 👉 First Fix the batteries in the battery holder given on the side part of the sanitizer device and turn on the switch.
- 👉 Now place the hand under the dispensing nozzle, and remove the hand after it releases the liquid.
- 👉 Rub hands together covering all the surfaces of hands and fingers.
- 👉 Rub until liquid sanitizer is absorbed.



### Points to Remember:

- 👉 Use only Thin Liquid Sanitizers.. Do not use GEL type Sanitizers.
- 👉 When Air Locked, connect a straw to the nozzle and blow air. Always maintain required sanitizer level to avoid airlock.



### Features

- 1) Non touch, hands free
- 2) Automatic release of liquid when hands are placed under the dispense nozzle.
- 3) Can adjust the distance of sensor to sense the hands (short to long) by adjusting the screw provided below the dispensing box.

**For Online Order Contact**



+919063333399



sales@scientys.com

web:www.scientys.com